alinefurniture@sasktel.net (306) 682-2154

## A-LINE FURNITURE & APPL LTD



Fit all of your fresh and frozen favorites without sacrificing any space with the 28" wide top-freezer refrigerator with 14 cu. ft. capacity. Enjoy quiet cooling with improved design and ice cold temperatures inside with freezer temperature controls. And you'll always have plenty of ice on hand with the optional icemaker

in the top-freezer refrigerator.

# Whirlpool 28" Wide Top-Freezer Refrigerator with Freezer Temperature Control

Exterior

Cabinet Finish

Handle Material

Door Style

Hidden Hinge

Reversible Door

Door Color

WRT134TFDW

## Available Finishes/Colours

WRT134TFDB	WRT134TFDM
Black	Monochromatic Stainless Steel
WRT134TFDW White	

Dimensions	
Depth	32 1/8
Height	62 7/8
Width	28

AHAM Volumes And Shelf Area					
Freezer Volume (Cu Ft)	3.87				
Refrigerator Volume (Cu Ft)	10.46				
Details					

Details			
Cooling Type	Single Evaporator		
Counter Depth	No		
Door Style	Flat		

Configuration and Overview			
Counter Depth	No		
Levelers	2 Black		
Exterior			
Cabinet Color	White		

Door Finish	Textured			
Handle Material	Plastic			
Door Opening	Right			
Door Style	Flat			
Handle Color	White			
Handle Type	Reach-Through Handle			
Levelers	2 Black			
Wheels	4-Natural			
Hidden Hinge	No			
Reversible Door	Yes			
Appearance				
Cabinet Finish	Textured			

Textured

White

**Plastic** 

Flat

No

Yes

Top Features
Optional Icemaker
Quiet Cooling
ENERGY STAR® Certified
Manuals & Literature:  Dimension Guide  Energy Guide  Use and Care Guide  Warranty Information





## **Top Mount Refrigerator**

#### PRODUCT MODEL NUMBERS

WRT104TFD WRT134TFD WRT314TFD

**Electrical:** A 115-volt, 60-Hz, AC-only, 15-or 20-amp fused, grounded electrical supply is required. It is recommended that a separate circuit serving only your refrigerator be provided. Use an outlet that cannot be turned off by a switch. Do not use an extension cord.


NOTE: Before performing any type of installation, cleaning, or removing a light bulb, turn the control (Thermostat, Refrigerator or Freezer Control depending on the model) to OFF and then disconnect the refrigerator from the electrical source. When you are finished, reconnect the refrigerator to the electrical source and reset the control (Thermostat, Refrigerator or Freezer Control depending on the model) to the desired setting. See "Using the Controls."

**Water:** A cold water supply with water pressure between 30 and 120 psi (207 and 827 kPa) is required to operate ice maker and water dispenser. If you have questions about your water pressure, call a licensed, qualified plumber.

**IMPORTANT:** The pressure of the water coming out of a reverse osmosis system going to the water inlet valve of the refrigerator needs to be between 30 and 120 psi (207 and 827 kPa).


Reverse Osmosis Water Supply: If a reverse osmosis water filtration system is connected to your cold water supply, the water pressure to the reverse osmosis system needs to be a minimum of 40 to 60 psi (276 to 414 kPa).

### PRODUCT DIMENSIONS



Model Number	Model Size	Reversible Doors	Height - Overall "A"	Height - Top of Cabinet "B"	Depth - Door Open 90° "C"	Depth - With Handles "D"	Depth - Without Handles "E"	Depth - Cabinet Only "F"	Width - Cabinet "G"
WRT104TFD WRT314TFD	14.3 cu. ft.	Yes	62 <sup>7</sup> /" (159.7 cm)	62 <sup>3</sup> /" (158.4 cm)	56 <sup>3</sup> /" (144.1 cm)	32½" (82 cm)	30" (76.2 cm)	25 <sup>1</sup> /" (64.1 cm)	28" (71.1 cm)
WRT134TFD	14.3 cu. ft.	Yes	62 <sup>7</sup> /" (159.7 cm)	62 <sup>3</sup> /" (158.4 cm)	55 <sup>3</sup> /" (141.6 cm)	32 <sup>1</sup> /" (81.6 cm)	29 <sup>7</sup> /" (75.9 cm)	25 <sup>1</sup> /" (64.1 cm)	28" (71.1 cm)
WRT106TFD	16 cu. ft.	Yes	65 <sup>7</sup> /" (167.3 cm)	65 <sup>3</sup> /" (166 cm)	56³/" (144.1 cm)	33 <sup>1</sup> /" (85 cm)	31 <sup>1</sup> /" (79.4 cm)	25 <sup>1</sup> /" (64.1 cm)	28" (71.1 cm)

## **LOCATION REQUIREMENTS**



To ensure proper ventilation for your refrigerator, allow for a  $\frac{1}{2}$ " (1.25 cm) space on each side. Allow 3" (7.5 cm) of space between overhead cabinets and refrigerator top. Allow at least 1" (2.5 cm) between back of cabinet and the wall. If your refrigerator has an ice maker, make sure you leave some extra space at the back for the water line connections.

If you are installing your refrigerator next to a fixed wall, leave enough space on the hinge side to allow for the door to swing open.

**NOTE:** This refrigerator is intended for use in a location where the temperature ranges from a minimum of 55°F (13°C) to a maximum of 110°F (43°C). The preferred room temperature range for optimum performance, which reduces electricity usage and provides superior cooling, is between 60°F (15°C) and 90°F (32°C). It is recommended that you do not install the refrigerator near a heat source, such as an oven or radiator.